



The 6pin connector serves both for flashing new firmware into the Attiny84A and for connecting to a PC to download of the acquired GPS records.

The 3.3V is generated from Vin, inside the GPS engine. It is used to power the ATtiny84 and the EEPROM.

UAV GPS Tracker

Design by H. Dingfelder
www.herbert-dingfelder.de

Sheet: /		Date:	
File: UAV_GPS_tracker.sch		Rev:	
Size: A4	KiCad E.D.A. kicad 0.201507042246+588423ubuntu14.04.1-product		Id: 1/1